Three Mode WiFi Switch

Model: TYWB 2CH-B1
TYWB 2CH 7-32V RF

Parameters:

Input voltage: DC/AC 7V~32V
Max.Current:2200W/10A
Wireless:Wi-Fi 2.4ghz b/g/n+Bluetooth
Radio Frequency:433MHz
Working temperature: -20℃~70℃
Size: 116*38*25mm

Checklist before using the device

- Your smart phone or tablet has connected to a 2.4g WiFi with internet.
- You need to enable Bluetooth of the phone.
- You have the correct WiFi PWD.
- You smart phone or tablet must have access to APP store/Google play.
- Your router is MAC-open.

❶ Device pairing
Gerätekopplung
Appareiment d'appareils
Aldeinamento del dispositivo
Emparejamiento de dispositivo
デバイスペアリング

❷ Download the Tuya smart or Smart life App
Laden Sie die Tuya smart App herunter
Téléchargez l'application Tuya smart
Scarica l'applicazione tuya smart
Descarga la aplicación tuya smart
tuya smart アプリをダウンロード

tuya smart

❸ After powering on, it enters the network pairing state (default, and the network indicator flashes rapidly (1 time / second).

Nach dem Einschalten befindet es sich standardmäßig im Netzwerkkopplungsmodus, und die Netzwerkanzeige blinkt schnell (2 Mal/Sekunde).

Après la mise sous tension, il entre en mode d'appariement réseau par défaut, et le voyant réseau clignote rapidement (2 fois/seconde).

Dopo l'accensione, entra nello stato di accoppiamento di rete per impostazione predefinita, e l'indicatore di rete lampeggia rapidamente (2 volte/secondo).

Después de encenderse, entra en el estado de emparejamiento en red por defecto, y el indicador de red parpadea rápidamente (2 veces/segundo).

電源を入れると、デフォルトでネットワークペアリング状態になり、ネットワークインジケータが高速に点滅します（1回/秒）。

❹ If the network indicator is not lit, press and hold the device reset button for 5 seconds until the network indicator changes to flashes rapidly(2times/second).

wenn die Netzwerkanzeige nicht leuchtet, drücken und halten Sie die Geräterücksetze 5 Sekunden lang, bis die Netzwerkanzeige in schnellen Blinken (2 Mal/Sekunde) übergeht

Si le voyant réseau n'est pas allumé, appuyez et maintenez enfoncé le bouton de réinitialisation de l'appareil pendant 5 secondes jusqu'à ce que le voyant réseau passe en clignotant rapide (2 fois/seconde).

Se l'indicatore di rete non è acceso, premere e tenere premuto il pulsante di reset del dispositivo per 5 secondi finché e quando l'indicatore di rete passa a lampeggio rapido (2 volte/secondo).

Si el indicador de red no está encendido, presione y mantenga presionado el botón de reinicio del dispositivo durante 5 segundos hasta que el indicador de red cambie a parpadeo rápido (2 veces/segundo).

ネットワークインジケータが点灯していない場合、デバイスのリセットボタンを5秒間押し続け、ネットワークインジケータが高速点滅（1回あたり2回）に変わるまで待ちます。

❺ Open the Tuya smart App, tap on the top-right corner + select "Add Device".

Öffnen Sie die Tuya Smart App, tippen Sie oben rechts auf + und wählen Sie "Gerät hinzufügen".

Ouvrez l'application Tuya Smart, appuyez en haut à droite sur +, puis sélectionnez "Ajouter un appareil".

Apri l'app Tuya Smart, tocca l'angolo in alto a destra +, seleziona "Aggiungi dispositivo".

Abre la aplicación Tuya Smart, toca en la esquina superior derecha en +, selecciona "Agregar dispositivo".

Tuya Smart アプリを開き、右上隅の+をタップし、デバイスを追加を選択します。

❻ Wait for a few seconds, tap" Add" when the device is found.

Warten Sie einige Sekunden, tippen Sie auf "Hinzufügen", wenn das Gerät gefunden wurde.

Attendez quelques secondes, appuyez sur "Ajouter" lorsque le dispositif est trouvé.

Aspetta qualche secondo, tocca "Aggiungi" quando il dispositivo viene trovato.

Espere unos segundos, toque "Agregar" cuando se encuentre el dispositivo.

数秒待ち、デバイスが見つかったら「追加」をタップします。

❼ Select your WiFi, enter the WiFi password, and tap "Next".When successful addition, tap"Done"

Wählen Sie Ihr WLAN aus, geben Sie das WLAN-Passwort ein und tippen Sie auf "Weiter". Nach erfolgreicher Hinzufügung, tippen Sie auf "Fertig".

Sélectionnez votre WiFi, entrez le mot de passe WiFi, puis cliquez sur "Suivant". Après l'ajout réussi, cliquez sur "Terminer"

Seleziona la tua rete WiFi, inserisci la password WiFi, quindi clicca su "Avanti". Dopo l'aggiunta riuscita, clicca su "Fine".

Selecciona tu WiFi, introduce la contraseña del WiFi y haz clic en "Siguiente". Después de una adición exitosa, haz clic en "Hecho".

WiFiを選択し、WiFiパスワードを入力して、「次へ」をタップします。追加が成功したら、「完了」をタップします。

Remote control matches the code

Matching:

❶ hold the manual switch for 3 seconds you want to match,until RF indicator(blue light) on.

❷ then long press the remote control button you want to match.

❸ loosen the remote control buttons,matching success.

Match other buttons, repeat steps ❷ to ❸

Clear code:

Long press the manual switch for 15 seconds you want to clear (RF indicator is always on), until RF indicator(blue light) is off,then loosen the manual switch.

* note: the matching/clear code method is only available with RF function switch/module reference

TROUBLESHOOTING

Solutions for the failure of product matching and offline:

Enter the homepage of App,click the icon in the lower right corner of the interface to enter.

CE RoHS

MADE IN CHINA